

INSTALLATION INSTRUCTIONS FOR THE CUSTOMIZED WINDSHIELD WRAP

1. BEGIN BY BENDING YOUR TRACK CLOSE TO THE RADIUS OF YOUR WINDSHIELD. NOTE: BECAUSE OF UPS SHIPPING LIMITS ON LENGTH, YOUR TRACK COULD SHIP IN 2 OR 3 PIECES.
2. SLIDE MOUNTING BRACKETS (A) ONTO THE RAIL. BEGIN INSTALLING BRACKETS EVERY 12 - 16 INCHES.
3. SLIDE I-BEAM ROLLERS ONTO THE TRACK (B).
4. PLACE STOPS (C) ON END OF EACH TRACK SECTION.
5. SCREW EACH END SECTION INTO THE WALL (D).
6. MOUNT STRAP (E).

