



An *AIRXCEL* Brand

Installation Instructions for the Customized Cockpit Window Wrap

1. Begin by carefully bending your track (B) close to the radius of your windshield. **NOTE:** Because of UPS shipping limits on length, your track could ship in 2 or 3 pieces.
2. Slide ceiling mount brackets (A) onto the track (B). Install ceiling mount brackets every 12 –16 inches to anchor rail.
3. Slide I-beam rollers (C) onto the track (B).
4. Place stops (D) on end of each track section.
5. Mount end section into the wall (E) while installing strap (F) at the midpoint.
6. Use wand (G) to open and close windshield wrap.

