

Pleated Folding Door Instructions

A. Installing Ceiling Track (*Detail 1*)

1. Place track into door jamb and install the first two screws approximately 12 inches apart. (Do not install all the screws into the track at this point)

2. Place the door onto the track by pulling down on the unscrewed portion of the track and inserting the glides into the track.

Proceed with installing the remaining screws into the top track.

B. Mount back PVC rail to wall jamb. (*Detail 2*)

C. Installing Door Catch (*Detail 3*)

Note: Proper alignment of door catch is critical for a custom fit.

1. Remove male part of catch from plastic bag taped to your door.
2. Insert the screw into the male part of the door catch.
3. Snap the male piece into the door catch with the missing screw facing out.
4. Pull the door closed pressing the catch against the door jamb--leaving a small mark where the screw hit.
5. Remove the male piece from the door and screw into the door jamb where the screw mark was imprinted.

