



a **dicor** company

Installation Instructions for the Customized Cockpit Window Wrap

1. Begin by carefully bending your track (C) close to the radius of your windshield. **NOTE:** Because of UPS shipping limits on length, your track could ship in 2 or 3 pieces.
2. Slide Mounting Brackets, (A) for mounting to the wall and (B) for mounting to the Ceiling or Overhead Cabinet, onto rail (C). Install appropriate brackets every 12 – 16 inches.
3. Slide I-Beam Rollers (D) onto the track (C) (Detail 1).
4. Place stops (E) on end of each track section (Detail 1).
5. Mount end section into the wall (F) while installing Strap (G) at the center (Detail 2).
6. Use Wand (H) to open and close windshield wrap.

